

CLEAR ACRYLIC HYGIENIC SCREEN

PROTECTIVE FILM COVERS

All our sneeze screens come with a protective film on both sides of the Acrylic. Please remove these prior to use.

FITTING INSTRUCTIONS

All our screens are acrylic formed and we always recommend they are fixed to your counter or desk with a High bond Double Sided Tape (ideally a Gel Tape), or screwing using 2 or 4 fixing points.

For screwing, please use a sharp metal drill bit for your pilot hole, and using a drill at high speed drill slowly through the acrylic base ideally also using masking tape over the hole before you start. You should always drill a pilot hole (approx 4- 5 mm) before you screw into the counter using screws. Do not over tighten the screws.

CLEANING and AFTERCARE

The screens are durable to most cleaning chemicals and should be cleaned with a soapy water solution or window cleaner spray.

Any questions, please do not hesitate to contact us.